Bona Hard Wax Oil



Application on untreated wood

This instruction is for standard application of Bona Hard Wax Oil on untreated wood. For other combinations/ways of using see separate instruction.

Preparations

Ensure floor is acclimatized to its end-use environment, well sanded, dry and free from sanding dust, wax and other contamination. Allow product to reach room temperature and <u>stir</u> the container thoroughly before use. Optimal application conditions are between 20-25°C and 30-60% relative air humidity. High temperatures and low humidity shorten drying time, low temperatures and high humidity lengthen drying time. **Minimum temperature for use is 16°C**.

Note: Hard Wax Oil may exhibit curing problems on tropical wood species such as ipé, wenge, merbau etc. To improve the curing conditions on these timbers and the like, it is recommended to apply one coat of Bona Craft Oil Neutral which is then allowed to dry before using Hard Wax Oil.

Treatment schedule

• 2x Bona Hard Wax Oil

Application

- 1. Stir the container with Bona Hard Wax Oil and pour the content into a tray. Apply very thinly using a short-haired mohair roller or a fine brush. Work in small sections and overlap wet-on-wet. Let dry min 6-8 hours*.
- 2. Lightly abrade the surface using a Bona Scrad Pad and remove the dust.
- 3. Apply a second thin coat of Bona Hard Wax Oil.
- 4. Let dry minimum 16 hours* before resuming foot traffic. Ensure good ventilation during application and drying.

WARNING: BONA HARD WAX OIL CONTAINS DRYING OILS. RISK OF SELF-IGNITION. USED CLOTHS, RAGS AND SIMILAR SHOULD BE PLACED IN WATER OR SEALED METAL CONTAINERS.

* drying time at 20 °C/60% RH, expect longer drying time on exotic wood and at low temperatures. The room can normally be furnished after 1-2 days but wait approx. 1 week before covering the surface with carpets or cleaning with wet methods.

Maintenance

Clean the floor regularly using a dry mop and/or a vacuum cleaner. When needed, wipe off with a damp mop with Bona Soap added to the cleaning water. **Note:** Always clean using as dry a method as possible. For maintenance and upkeep of the surface use Bona Wax Oil Refresher periodically. The frequence of this operation is determined by the level of wear and may range from every 3rd year in a domestic environment to a few times a year in a commercial environment. As an extended maintenance it is also possible to apply additional layers of Bona Hard Wax Oil.

Recoating

- 1. Degrease and clean the surface with the Bona Deep Clean System. Let dry.
- 2. Abrade surface with a Bona Scrad Pad or Bona Diamond Abrasives grit 240.
- 3. Remove sanding dust.
- 4. Apply a thin layer of Bona Hard Wax Oil and let dry.

March 2013 This data sheet replaces all previous versions

Bona Hard Wax Oil

Application on untreated wood

Detailed maintenance instructions are available at www.bona.com

Important notes

The information provided is prepared to the best of our current knowledge and makes no claim to be complete. User is responsible for establishing that the product and recommendations herein are fit for the designated purpose, wood type and present situation before use. Bona can only guarantee the delivered product. A professional and thereby successful application of the product is beyond our control. If in doubt make a preliminary test or contact Bona's technical service. User is required to read and understand all information contained on package labels and safety data sheets before using this product.



